

## Product Information & Installation Guide

### Rubber Compliant Speed Humps and Rubber Compliant Ends (Concrete Surfaces)





#### **Speed Humps**

Australian Compliant - Complies with AS2890.1:2004.

SKU: SHRUBCOM

Description: Rubber Speed Hump

Material: Rubber Height: 50mm Length: 250mm Depth: 350mm Weight: 4kg 1 Year Warranty

#### **Speed Hump Ends**

Australian Compliant - Complies with AS2890.1:2004.

SKU: SHRUBCOMEND

Description: Rubber Speed Hump Ends

Material: Rubber Height: 50mm Length: 350mm Width: 180mm Weight: 1.8kg 1 Year Warranty

#### **Installation Guide**

#### You will need:

- A hammer drill with a 14mm masonry drill bit
- The M10 screw fixings supplied with the wheel stops.
- A 17mm socket
- A hammer
- A hand broom or industrial vacuum (optional)

# Fixings required for concrete surfaces.

#### What to do:

- 1. Read all the instructions from beginning to end first.
- 2. Determine exactly where the speed hump will be placed. It is a good idea to mark the ground to ensure that you have a straight line to assist you with the correct placement of your speed humps. Don't forget to include the speed hump ends in your measurements, if you are installing them also.
- 3. Put the first segment of speed hump where it will go and using your hammer drill, drill a guide hole in the concrete through each hole in the speed hump using the 14mm masonry drill bit. (This is to mark the surface so that you know where to continue to drill).
- 4. Remove the speed hump and brush or vacuum away the concrete dust.
- 5. Continue to drill each guide hole to an approximate depth of 120mm.
- 6. Brush or vacuum away the concrete dust.
- 7. Put the plastic plug component of the fixing in the drilled hole and hammer in.
- 8. Place the speed hump over the holes, line up and place the supplied M10 screw through the speed hump and into the plastic plug.
- 9. Use your 17mm socket to tighten the M10 screw.
- 10. Repeat this process for each segment of the speed hump and the speed hump ends if you are installing them also.

For a seamless installation, ensure your speed humps are placed on a flat surface.

Safety Xpress recommends you put the safety of yourself and others first when installing your speed humps. Please be mindful of using and wearing the correct safety gear.