



INSTALLATION GUIDE

BOLLARD- SLIDER SURFACE MOUNT REMOVABLE

YOU WILL NEED:

- A hammer drill with the correct size drill bit
- The fixings for the bollard
- A hand broom or industrial vacuum (optional)

WHAT TO DO:

1. Read all the instructions from beginning to end first.
2. Determine exactly where the bollard will be placed. If you are installing more than one bollard, it is a good idea to mark the ground to ensure that you have a straight line to assist you with the correct placement of your bollards.
3. Using your hammer drill, drill a guide hole in the surface, through each hole in the bollard plate using the drill bit. (This is to mark the surface so that you know where to continue to drill).
4. Remove the bollard and brush or vacuum away the dust.
5. Continue to drill each guide hole to almost the entire length of your fixings.
6. Brush or vacuum away the surface dust.
7. Place each bollard plate over the holes, line up and put the supplied screws through the bollard plate, tightening them so that the surface is flush.
8. Turn the key and hold it while you slide the bollard into place.



TIP: FOR A SEAMLESS INSTALLATION, ENSURE YOUR BOLLARDS ARE PLACED ON A FLAT SURFACE

Safety Xpress recommends you put the safety of yourself and others first when installing your bollards. Please be mindful of using and wearing the correct safety gear.

WWW.SAFETYXPRESS.COM.AU