



INSTALLATION GUIDE

BOLLARD- SURFACE MOUNT

YOU WILL NEED:

- A hammer drill with the correct sized drill bit
- The fixings for the bollard
- The correct sized socket
- A hammer
- A hand broom or industrial vacuum (optional)

WHAT TO DO:

1. Read all the instructions from beginning to end first.
2. Determine exactly where the bollard will be placed. If you are installing more than one bollard, it is a good idea to mark the ground to ensure that you have a straight line to assist you with the correct placement of your bollards.
3. Using your hammer drill, drill a guide hole in the surface, through each hole in the bollard using the drill bit. (This is to mark the surface so that you know where to continue to drill).
4. Remove the bollard and brush or vacuum away the dust.
5. Continue to drill each guide hole to almost the entire length of your fixings.
6. (If you are using a plastic plug component, put it in the drilled hole and hammer in).
7. Place the bollard over the holes, line up and place your fixing in the holes and screw or hammer in.
8. Use your socket to tighten the screw if applicable. Be careful not to overtighten.



TIP: FOR A SEAMLESS INSTALLATION, ENSURE YOUR BOLLARDS ARE PLACED ON A FLAT SURFACE

Safety Xpress recommends you put the safety of yourself and others first when installing your bollards. Please be mindful of using and wearing the correct safety gear.

WWW.SAFETYXPRESS.COM.AU