



INSTALLATION GUIDE

SPEED HUMPS/TRAFFIC CALMER/SPEED CUSHIONS

YOU WILL NEED:

- A hammer drill with the correct sized drill bit
- The fixings supplied with the speed humps
- The correct sized socket
- A hammer
- A hand broom or industrial vacuum (optional)

WHAT TO DO:

1. Read all the instructions from beginning to end first.
2. Determine exactly where the speed hump will be placed.
3. Put the speed hump where it will go and using your hammer drill, drill a guide hold in the surface, through each hole in the speed hump using the drill bit. (This is to mark the surface so that you know where to continue to drill).
4. Remove the speed hump and brush or vacuum away the dust.
5. Continue to drill each guide hole to almost the entire length of your fixings.
6. (If you are using a plastic plug component, put it in the drilled hole and hammer in).
7. Place the speed hump over the holes, line up and place your fixing in the holes and screw or hammer in.
8. Use your socket to tighten the screw if applicable.



TIP: FOR A SEAMLESS INSTALLATION, ENSURE YOUR SPEED HUMPS ARE PLACED ON A FLAT SURFACE

Safety Xpress recommends you put the safety of yourself and others first when installing your speed humps Please be mindful of using and wearing the correct safety gear.