




Product Information & Installation Guide


Rubber Compliant Wheel Stops (Asphalt/Gravel Surfaces)

		<p>Australian Compliant - Complies with AS2890.1:2004.</p> <p>Specifications</p> <p>SKU: WSTOPAF</p> <p>Description: Rubber Wheel Stop</p> <p>Material: Rubber</p> <p>Finish: Yellow Reflective Panels</p> <p>Height: 100mm</p> <p>Length: 1650mm</p> <p>Weight: 16kg</p>
		<p>SKU: WSTOPDBLAG</p> <p>Available with BLUE reflective epoxy panels for use in Disabled Bays</p> <p>1 Year Warranty</p>

Installation Guide



You will need:

- A hammer drill with a 14mm masonry drill bit
- The road spikes supplied with the wheel stops.
- A hammer
- A hand broom or industrial vacuum (optional)



What to do:

1. Read all the instructions from beginning to end first.
2. Determine exactly where the wheel stop will be placed. See our handy chart below for the Australian Standards (AS2890.1:2004)



3. Put the wheel stop where it will go and using your hammer drill, drill a guide hole in the concrete through each hole in the wheel stop using the 14mm masonry drill bit. (This is to mark the surface so that hammering is made easier).
4. Remove the wheel stop and brush or vacuum away the dust if required.
5. Continue to drill each guide hole to an approximate depth of 120mm.
6. Place the wheel stop over the holes, line up and hammer the supplied road spikes through the wheel stop and into the road surface.

For a seamless installation, ensure your wheel stops are placed on a flat surface.

Safety Xpress recommends you put the safety of yourself and others first when installing your wheel stops. Please be mindful of using and wearing the correct safety gear.