

## Surface Mount Bike Hoop



Specifications	
<b>Product</b>	Surface Mount Bike Hoop
<b>Material</b>	Hot Dip Galvanised Steel OR 304 Grade Stainless Steel OR 316 Marine Grade Stainless Steel
<b>Colour</b>	Silver
<b>Dimensions:</b>	<b>Diameter:</b> 48mm O.D <b>Height:</b> 800mm <b>Width:</b> 800mm <b>Wall Thickness:</b> 3mm
<b>Item Weight</b>	9kg
<b>Fixings</b>	Standard Fixings Supplied with purchase (6pc x M10 120mm screws)

### Tools Required:

- Hammer drill with a 14mm masonry drill bit
- M10 screw fixings supplied with the bike hoop.
- 17mm socket
- Broom or industrial vacuum

### Installation:

1. Read instructions from beginning to end first.

2. Determine exactly where the bike rack will be placed and mark your installation positions.

If you are installing more than one bike rack, use a string line to ensure that you have a straight line to correctly place your bike racks.

3. Using your hammer drill, drill a guide hole in the concrete through each hole in the bike hoops using the 14mm masonry drill bit. (This is to mark the surface so that you know where to continue to drill).

4. Remove the bike hoop and brush or vacuum away the concrete dust.

5. Continue to drill each guide hole to an approximate depth of 120mm.

6. Brush or vacuum away the concrete dust.

7. Put the plastic plug component of the fixing in the drilled hole and hammer in.

8. Place each bike hoop over the holes, line up and put the supplied M10 screws through the bike hoop and into the plastic plugs.

9. Use your 17mm socket to tighten the M10 screws. Be careful not to overtighten the screws.

Safety Xpress recommends you put the safety of yourself and others first when installing your bike hoop.


Please be mindful of using and wearing the correct safety gear.

### Installation Service Available

Enquire about our installation services on 1300 049 246



**Technical Drawing**



					Technical Drawing