



INSTALLATION GUIDE

WHEELSTOPS

YOU WILL NEED:

- A hammer drill with the correct sized drill bit
- The fixings supplied with the wheelstop
- The correct sized socket
- A hammer
- A hand broom or industrial vacuum (optional)

WHAT TO DO:

1. Read all the instructions from beginning to end first.
2. Determine exactly where the wheelstop will be placed. See our handy chart in our Product Placement Guide for the Australian Standards (AS2890.1:2004).
3. Put the wheelstop where it will go and using your hammer drill, drill a guide hole in the surface, through each hole in the wheelstop using the drill bit. (This is to mark the surface so that you know where to continue to drill).
4. Remove the wheelstop and brush or vacuum away the dust.
5. Continue to drill each guide hole to almost the entire length of your fixings.
6. (If you are using a plastic plug component, put it in the drilled hole and hammer in).
7. Place the wheelstop over the holes, line up and place your fixing in the holes and screw or hammer in.
8. Use your socket to tighten the screw if applicable.

TIP: FOR A SEAMLESS INSTALLATION, ENSURE YOUR WHEELSTOPS ARE PLACED ON A FLAT SURFACE



IF LINEMARKING IS BEING COMPLETED IN A NEW CAR PARK, HAVE THIS DONE BEFORE WHEELSTOPS ARE INSTALLED. WHY? LINEMARKING MACHINES WILL REQUIRE FULL ACCESSIBILITY OF THE CARPARK BEFORE THE WHEELSTOPS ARE INSTALLED.

Safety Xpress recommends you put the safety of yourself and others first when installing your wheelstops. Please be mindful of using and wearing the correct safety gear.