


## Heavy Duty Steel Speed Humps and Heavy Duty Steel Ends (Concrete Surfaces)



8 fixings required for each section



4 fixings required for each end section.

### Speed Humps

Australian Compliant - Complies with AS2890.1:2004.

SKU: SHSTEEL1M

Description: Heavy Duty Steel Speed Humps

Material: Hot Dipped Galvanised Metal

Height: 55mm

Length: 1metre module

Depth: 430mm

Weight: 26.0KGS

Steel gauge: 6mm

Weight rated to 50 Tonne

1 Year Warranty

### Speed Hump Ends

Australian Compliant - Complies with AS2890.1:2004.

SKU: SHSTEELEND

Description: Heavy Duty Steel Speed Hump End

Material: Hot Dipped Galvanised Metal

Height: 55mm

Length: 200mm

Depth: 430mm

Weight: 5.00 KGS

Steel gauge: 6mm

Weight rated to 50 Tonne

1 Year Warranty

## Installation Guide-

### You will need:

- A hammer drill with a 14mm masonry drill bit
- The M10 screw fixings supplied with the speed humps
- A 17mm socket
- A hammer
- A hand broom or industrial vacuum (optional)

### What to do:

1. Read all the instructions from beginning to end first.
2. Determine exactly where the speed hump will be placed. It is a good idea to mark the ground to ensure that you have a straight line to assist you with the correct placement of your speed humps. Don't forget to include the speed hump ends in your measurements, if you are installing them also.
3. Put all of the speed humps where they will go, making sure they sit tightly against each other. Using your hammer drill, drill a guide hole in the concrete through each hole in the speed humps using the 14mm masonry drill bit. (This is to mark the surface so that you know where to continue to drill).
4. Remove the speed humps and brush or vacuum away the concrete dust.
5. Continue to drill each guide hole to an approximate depth of 120mm.
6. Brush or vacuum away the concrete dust.
7. Put the plastic plug component of the fixing in the drilled hole and hammer in.
8. Place each speed hump over the holes, line up and put the supplied M10 screw through the speed hump and into the plastic plug.
9. Use your 17mm socket to tighten the M10 screws.
10. Repeat this process for each segment of the speed hump and the speed hump ends if you are installing them also.

For a seamless installation, ensure your speed humps are placed on a flat surface.

*Safety Xpress recommends you put the safety of yourself and others first when installing your speed humps.  
Having assistance to lift and install these 26kg speed humps is a good idea.  
Please be mindful of using and wearing the correct safety gear.*

